



ClampStar Newsletter

February, 2010

[Click Here to View a 90 Second Video Demo](#)



Need to replace failing Splices, Deadends or Suspension Clamps? Need to up-rate lines? Use ClampStar and do it Faster, Safer, Easier.....

- Splice replacement no longer necessary!
- Installs in a few minutes with 1 man and a Hot Stick!
- No Mechanical Grips, Come-Alongs, Jumper Cables or Cutters needed
- Restores electrical and mechanical integrity on weathered conductors
- Handles both Transmission and Distribution applications
- Significantly safer than traditional splice replacement
- Increase ampacity / Up-rate systems simply & inexpensively
- Exceeds ANSI C119.4 Class AA EXTRA HEAVY DUTY!

Read T&D World article by clicking here: [Resistance Measurements Enable Avista to Detect and Remove Failing Splices.](#)

Video demonstration available by clicking here: [ClampStar Video](#)

Order a sample today! Please visit www.ClampStar.com to find a supplier near you.

Installation photos available online at www.ClampStar.com

Please contact us for additional information.

Sincerely,
Chris Costanzo
Classic Connectors, Inc.
800-269-1462 Ext.1